

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://waeco.nt-rt.ru/> || woc@nt-rt.ru

Защитные аксессуары для отфильтровывания герметиков из систем кондиционеров

WAECO ASC-RCYGRD



Recycle Guard, R134a

The Recycle Guard is a practical accessory that filters out sealants from automotive A/C systems before they can enter and cause damage to your service unit. Installation is quick and easy: simply fit the guard between the A/C service unit and the air conditioning system before commencing a service. You can also permanently attach the Recycle Guard to your A/C service unit with an optional mounting bracket.

- Filters out sealants from automotive A/C systems before they can enter and cause damage to your service unit.
- Can be permanently attached to your A/C service unit with a mounting bracket (available separately)
- Compatible with A/C service units of all makes
- Integrated filter insert can be used several times
- Designed for R134a systems (a different model for R1234yf systems is also available)

**Описание изделия Recycle Guard, R134a
Для хладагента R134a**

WAECO ASC-RCYGRD



Recycle Guard, R1234yf

The Recycle Guard is a practical accessory that filters out sealants from automotive A/C systems before they can enter and cause damage to your service unit. Installation is quick and easy: simply fit the guard between the A/C service unit and the air conditioning system before commencing a service. You can also permanently attach the Recycle Guard to your A/C service unit with an optional mounting bracket.

-
- Filters out sealants from automotive A/C systems before they can enter and cause damage to your service unit.
 - Can be permanently attached to your A/C service unit with a mounting bracket (available separately)
 - Compatible with A/C service units of all makes
 - Integrated filter insert can be used several times
 - Designed for R1234yf systems (a different model for R134a systems is also available)

Описание изделия Recycle Guard, R1234yf Для хладагента R1234yf

WAECO ASC-RCYGRD



Universal mounting bracket, Recycle Guard R134a/R1234yf

The Recycle Guard is a practical accessory that filters out sealants from automotive A/C systems before they can enter and cause damage to your service unit. This universal mounting bracket allows you to permanently attach the Recycle Guard to your A/C service unit.

-
- Enables you to permanently attach a Recycle Guard to your A/C service unit
 - Compatible with both Recycle Guard models (R134a and R1234yf)
 - Suitable for all A/C service units

Описание изделия Universal mounting bracket, Recycle Guard R134a/R1234yf Для хладагента R134a, R1234yf

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://waeco.nt-rt.ru/> || woc@nt-rt.ru